



Assembly Instruction For 2657

1. Spread the arms [1] evenly. Make sure each arm is aligned with the center rod [3], Also make sure that each scroll [2] is aligned with the arm.
2. Slide the Cluster set [4] and the loop set [5] down the wire until the cluster set sits on the distributor [6]. Aligned the cluster with the arms on the body.
3. Pass the threaded nipple [7] on the loop set through the center hole of the cluster. Turn the loop set clockwise to thread the nipple into the coupler [8]. Check to make sure the loop is tightened.
4. Refer to the Installation Instructions attached for wiring instructions.

